


GENERAL NOTES


1. SILT FENCE TO BE TYPICALLY INSTALLED DOWN SLOPE OF CONSTRUCTION ACTIVITIES AND ADJACENT TO STREAMS AND WETLANDS.
2. STORMWATER POLLUTION PREVENTION PLANS (SWPPP) WILL INDICATE LOCATIONS OF SILT FENCE INSTALLATION.
3. SWPPP WILL BE IN ACCORDANCE WITH NYS STANDARDS AND SPECIFICATIONS FOR EROSION AND SEDIMENT CONTROL (2005).

INSTALLATION NOTES


1. EXCAVATE A 4"x4" TRENCH ALONG THE LOWER PERIMETER OF THE SITE.
2. UNROLL A SECTION AT A TIME AND POSITION THE POSTS AGAINST THE BACK (DOWNSTREAM) WALL OF THE TRENCH (FABRIC SIDE AWAY FROM DIRECTION OF FLOW).
3. DRIVE THE POST INTO THE GROUND UNTIL THE FABRIC IS APPROXIMATELY 2" FROM THE TRENCH BOTTOM.
4. LAY THE TOE-IN FLAP OF FABRIC ONTO THE UNDISTURBED BOTTOM OF THE TRENCH, BACKFILL THE TRENCH AND TAMP THE SOIL. STEEPER SLOPES REQUIRE AN INTERCEPT TRENCH.
5. JOIN SECTIONS AS SHOWN.



TOP VIEW



JOINING SECTIONS OF FENCING



TOE-IN METHOD

SCALE: N.T.S.

**Appendix A  
Silt Fence**

**Jordanville Wind Power Project**

Towns of Warren and Stark  
Herkimer County, New York

Prepared By:



The Jordanville Wind Farm,  
a project of  
COMMUNITYENERGY

May 2006